



Wet Tap Procedures

Contractors Responsibilities

Before calling for a Wet Tap Inspection

1. Obtain Right of Way permit
2. Call for locates and provide a valid locate ticket to Seminole County Inspector
3. Provide MOT for public safety within the R/W
4. Install dewatering, sheeting, bracing or shoring (if required)
5. Excavate & verify the type and size of main to be tapped
6. Verify tapping sleeve is per Seminole County detail and Approved Materials list
7. Notify the inspector of any potential conflicts

During Wet Tapping Operations

1. Tapping sleeve to be located a minimum of 4' from any pipe joints, fittings or valves
2. Add #57 stone per Seminole County details
3. Install pressure gauge & perform pressure test (150 psi for 15 minutes)
4. Tapping valve and machine are to be supported properly & not cause undue stress on the main
5. Deliver pipe coupon to Inspector
6. Backfilling & compaction of excavated area
7. Restoration as required

It is recommended to have the 2" taps installed for the jumper assembly if the wet tap is installed on a Potable Water Main line.